

MT Box Nokia unlock BB5 without test point short user manual

- Contact your reseller to buy BB5 Unlock Without Test Point activation
- After your reseller inform you that your activation is ready
- Download and install MTB NK setup 1.54.exe software (or higher if any)
- Connect your MT box to USB
- Go to C:\Program Files\GriffinTeam\MT-Box\ and start MT box update tool v3.7 (do not use older version because will not work)
- Press info button to see it is communication ok
- Press UPDATE button and wait to software finish
- After successful activation log as bellow appears:

```
Device:<\\?\usb#vid_***0&pid_f00d#00xxxxxxxx#{e6ef7dcd-1795-4a08-9fbf-aa78423c26f0}>
SN:00xxxxxxxx
Getting BOX Status...OK
Getting INI File Update....[PIN:74xxxxxBFB3xxxxx]OK
SN:00xxxxxxxx
Server Login... OK
Ask...OK
Server I/O....OK
Updating...BOX is Updated!
```

- Update of box you need to do only first time
- Your box is ready for unlock BB5 without TP
- Close MT box update tool v3.7
- Start MTB NK 1.54 exe or higher
- Connect phone to box FBUS cable
- Phone need to be in LOCAL mode
- Press phone info button
- Press UNLOCK button